

Battery compatibility Chart for Sony NP-FW50

Depending on your country or region, some products displayed may not be available.

ZV-E10	NEX-7	SLT-A55	DSC-RX10M4
	NEX-6	SLT-A37	DSC-RX10M3
ILCE-7SM2	NEX-5T	SLT-A35	DSC-RX10M2
ILCE-7S	NEX-5R	SLT-A33	DSC-RX10
ILCE-7RM2	NEX-5N		
ILCE-7R	NEX-5		
ILCE-7M2	NEX-F3		
ILCE-7	NEX-C3		
ILCE-6500	NEX-3		
ILCE-6400			
ILCE-6300			
ILCE-6100			
ILCE-6000			
ILCE-5100			
ILCE-5000			
ILCE-3500			
ILCE-3000			
ILCE-QX1			